

CCPS IT Knowledge Base

Mouse pad is not working - Enabling / disabling mouse pad


If your mouse pad is not working, it may have been disabled. If you see an amber light on the F2 key, this means the mouse pad is disabled.



Follow the directions below to enable the keypad.

1. Press and hold the FN key.

2. Press the F2 key. The orange light should turn off.



Revision #2

Created 19 February 2025 17:24:29 by Clint Hunter

Updated 16 June 2025 19:22:23 by Clint Hunter

This information is for the staff, students, and parents/guardians at Campbell County Public Schools. Do not share this information with anyone not included in these groups.

You can view more help articles at kb.campbell.k12.va.us.